




Interchangeable USB Adaptor - Cigarette & Hella(Din) Plug

Operating Instructions

TC-6680UP

©2015 Cliff-Top Power Supply



- To switch the adaptor to Hella(Din) Plug: Press the four edges (red) together with negative rear, and then push these towards to the end.



- To switch the adaptor to Standard Cigarette Plug: Simply pull out the four edges (red) to the other end.

English

Interchangeable USB Adaptor

Features

- 2.1 Amp high power voltage for fast charging
- Built-in safety fuse to protect against shorts and surges.
- Locking light Hella(DIN) and Cigarette plug for secure fitting
- Blue LED indication light and water resistant cap

Specifications

Input DC 12 - 24 v, 30v Max; Output 5v, 2.1Amp Max
Product Dimensions: 63 x 2.8 x cm ; 79 g

Precautions

- Please keep your adaptor dry and clean at all times especially inside the USB Charging Ports.
- If any dust or water gets inside the charging points, you may experience some connectivity issues. For best performance, it's strongly recommended that you do not use this product during bad weather conditions.
- Before charging your digital devices, please ensure the cable(s) is/are securely placed in the adequate position. The cable(s) should not get into contact with any moving parts. They must be kept away from the hot engine for safety reasons.
- This Product is not suitable for children under 6 years old due to its small parts and sharp point/edge.
- Do not put weight or pressure on the adaptor as it may cause the adaptor to deform during long storage
- The water resistant cap may deteriorate due to long-term storage

Note on static electricity

In particularly dry air conditions, mild tingling may be felt. This is a result of static electricity accumulated in the body, and not a malfunction of the adaptor.

The effect can be minimized by wearing clothes made from natural materials.



Disposal of Old Electrical & Electronic Equipment (Applicable in the European Union and other European countries with separate collection systems)

This symbol on the product or on its packaging indicates that this product shall not be treated as household waste. Instead it shall be handed over to the applicable collection point for the recycling of electrical and electronic equipment. By ensuring this product is disposed of correctly, you will help to prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. The recycling of materials will help to conserve natural resources. For more detailed information about recycling of this product, please contact your local Civic Office, your household waste disposal service or the shop where you purchased the product.